
D6 Butterfly Valves



Technical Databook

Ver. 1









Butterfly valves and rotary actuators for Open/Close or modulating control

Nylon coated disc (D(U)6.. series) Key features

Rated pressure: 1600kPa Other technical data see page 5...7

	k_{ν}	[m ³ /r	1]	80	170	290	560	870	1340	2690	5540	7540	10300	14300	18900	24200
	DN [mn		n]	50	65	80	100	125	150	200	250	300	350	400	450	500
Ф	Wafer	D(U))6	DU650	DU665	DU680	DU6100	DU6125	DU6150	DU6200	DU6250	DU6300	D6350	D6400	D6450	D6500
Type	Lug	D(U))6L	DU650L	DU665L	DU680L	DU6100L	DU6125L	DU6150L	DU6200L	DU6250L	DU6300L	D6350L	D6400L	D6450L	D6500L
kv		[►Y	P54	NRVU24 NRVU23 AF24(-S) AF230(-S	0(-S)	SRVU AF	SRVU GRVU AF	GRVU	GRVU 2xGRVU	2xGRVU						
		ose _{II}	P67			-24-3-T -230-3-T		SY2	SY2	SY2 SY3	SY3 SY4	SY4	SY6	SY7 SY8	SY8	SY9
kv		- II	P54	NRVU24 AF24-SR		SRVU AF	SRVU GRVU AF	GRVU	GRVU 2xGRVU	2xGRVU						
	n dulat uator	- 11	P67			24P-T 230P-T		SY2	SY2	SY2 SY3	SY3 SY4	SY4	SY6	SY7 SY8	SY8	SY9

Stainless steel disc (D(U)6..S series) could be available on request.

Table of contents


Product overview / contents	3
The Belimo Butterfly valves	4
The sizing of Butterfly valves	5
D(U)6 Butterfly valves, wafer or lug pattern	6
Dimensions of Butterfly valves	7
NRVU rotary actuators	8
SRVU rotary actuators	11
GRVU rotary actuators	14
AF Spring return actuators	17
SY large torque rotary actuators	19
SY actuator operation instructions	22
D(U)6 valve installation and maintenance instructions	25
WD6-AF linkage kit installation instructions	26
WD6-NRSR linkage kit installation instructions	27
WD6-GR linkage kit installation instructions	28
WD6-2GR linkage kit installation instructions	29
SY actuator installation instructions	30

The Belimo Butterfly valves



Belimo D(U)6.. series Butterfly valves are designed to meet the stringent needs of HVAC and commercial applications requiring positive shut-off for liquids.


Valve design features



- 1 Mounting flange according to ISO 5211.
- 2 Square stem head for form-fit attachment of the rotary actuator.
- 3 Stem with EPDM O-ring seal.
- 4 RPTFE stem bearing
- 5 Valve body made of cast iron (DN50...300), spheroidal ductile iron (DN350...500).
- 6 Hole pattern for PN 6/10/16 (wafer type), PN16 (lug type).
- 7 Stem made of stainless steel 416.
- 8 Double-D-fit attachment of the stem to the throttling element.
- 9 Throttling element made of spheroidal ductile iron nylon coated or stainless steel 316(on request).
- 10 EPDM seat lining, integrated flange sealing.
- Double-D-fit of valve stem connecting with the valve disc produces close tolerance, easy disassembly. The disc can be self-adjusting to centralize due to this unique design. (DN50...300)
- The integrated flange sealing ensures positive connection of the valve body, seat and disc, and provides complete isolation of the media from the body. It makes field replacement simple and fast, can seal with slip-on or weld-neck flanges and without additional gaskets.
- The ball profile style seat eliminates elastomer movement and reduces seat tearing or fatiguing due to bunching.
- Double seals prevent media coming into the valve. The primary seal is achieved by an interference fit of the molded seat flat with the disc hub. The secondary seal is created when the stem diameter is greater than the seat stem hole.
- The disc casting is precision machined, hand polished then coated with nylon layer which gives a smooth and close disc-to-seat relationship.
- The three non-corrosive RPTFE (ReinforcedPolyTetraFluoroEthylene) bushings completely isolate the valve shaft from the body, resulting in increased control of the valve disc, lower valve seating torque and longer valve life.
- The nylon coated disc features a very good corrosion resistance superior resistance to a broad range of chemical environments, as well as very low coefficient of friction and excellent resistance to impact and ultra-violet radiation. The stainless steel 316 disc(on request) is rust proof, and can withstand highertemperature than nylon coated disc.

Additionally to satisfy higher IP requirement and large size butterfly automation, Belimo offers SY.. series rotary actuators being designed to mate with the D(U)6.. series Butterfly valves and other quarter turn valve applications.

SY.. actuator design features



- 1 Gearbox with hardened planetary gear.
- 2 Two adjusting stop screws for limiting of manual rotation angle.
- 3 Handwheel that acts directly on the planetary gear.
- 4 Motor protected by a thermostat.
- 5 Terminals.
- 6 Limit switches and two auxiliary switches.
- 7 Housing made of cast aluminum (IP67).
- 8 4 x M5 hexagonal screws for cover of housing.
- 9 Sight glass for position indicator (rotary cylinder).
- The patented gear drive mechanism provides efficient, smooth operation while allowing easy manual override at any time.
- With IP67 rating, easily visible position indicator, international standard ISO 5211 mounting system, internal thermal motor overload protection, heater, dual auxiliary Form C switches, and easily accessible wiring termination points.
- The units are easily visible in mechanical rooms with their characteristic Belimo orange color. Wiring diagrams included in all printed documentation, are also affixed to the outside of the housing on the permanently attached product label.
- The torque ranges are available from 35 to 3500 Nm.

Actuators designed for D(U)6 valves

Belimo AF.., NRVU.., SRVU.. and GRVU.. series rotary actuators use the best possible electric motors and gearings and also employ highly sophisticated electronics for the control. The universal product design makes installation, operation and service so much easier.



Kv Value [m³	/h]										
Туре	Siz	ze	90°	80°	70°	60°	50°	40°	30°	20°	10°
DU650/L	DN50	2"	80	75	57	39	27	21	16	6.9	1.09
DU665 /L	DN65	2.5"	170	142	99	64	42	30	19	7.5	.52
DU680 /L	DN80	3"	290	278	205	139	87	51	34	21	7.7
DU6100 /L	DN100	4"	560	404	270	173	105	67	46	26	6.3
DU6125 /L	DN125	5"	870	744	502	306	186	113	60	33	15.6
DU6150 /L	DN150	6"	1340	1185	720	472	294	171	94	47	25.9
DU6200 /L	DN200	8"	2690	2360	1483	956	617	362	211	88	52.0
DU6250 /L	DN250	10"	5540	3948	2364	1502	911	588	334	193	84.5
DU6300 /L	DN300	12"	7540	6147	3607	2083	1229	706	401	164	4.13
D6350 /L	DN350	14"	10300	9348	6233	3938	2380	1335	616	291	5.2
D6400 /L	DN400	16"	14300	12856	8571	5416	3237	1836	847	400	6.9
D6450 /L	DN450	18"	18900	17028	11352	7172	4334	2433	1122	530	9.5
D6500 /L	DN500	20"	24200	21893	14596	9222	5573	3128	1443	682	12

The maximum velocity in the butterfly valve is 9m/s (for Open/Close control)

Closing Pressure \triangle Ps and linkage — D(U)6../L nylon coated disc series

				IP54 Ac	tuato	r			IP67 Actuator							
Туре	NRVU [10Nm]	AF .		SRVU [20Nm]		RVU Nm]	2xGR [72]		SY1 [35Nm]	SY2 [90Nm]	SY3 [150Nm]	SY4 [400Nm]	SY6 [650Nm]	SY7 [1000Nm]	SY8 [1500Nm]	SY9 [2000Nm]
	∆Ps kPa	∆Ps kPa	Linkage WD6	∆Ps kPa	∆Ps kPa	Linkage WD6	∆Ps kPa	Linkage WD6	∆Ps kPa	∆Ps kPa	∆Ps kPa	∆Ps kPa	∆Ps kPa	∆Ps kPa	∆Ps kPa	∆Ps kPa
DU650/L	1200	1200	- AF	-	-	-	-	-	1200	-	-	-	-	-	-	-
DU665/L	1200	1200	- AF	-	-	-	-	-	1200	-	-	-	-	-	-	-
DU680/L	-	1200	- AF	1200	-	-	-	-	1200	-	-	-	-	-	-	-
DU6100/L	-	400	- AF	600	1200	- GR	-	-	1200	-	-	-	-	-	-	-
DU6125/L	-	-	-	-	1200	- GR	-	-	-	1200	-	-	-	-	-	-
DU6150/L	-	-	-	-	400	- GR	1200	-2GR	-	1200	-	-	-	-	-	-
DU6200/L	-	-	-	-	-	-	600	-2GR	-	600	1200	-	-	-	-	-
DU6250/L	-	-	-	-	-	-	-	-	-	-	600	1200	-	-	-	-
DU6300/L	-	-	-	-	-	-	-	-	-	-	-	1200	-	-	-	-
D6350/L	-	-	-	-	-	-	-	-	-	-	-	-	1200	-	-	-
D6400/L	-	-	-	-	-	-	-	-	-	-	-	-	-	600	1200	-
D6450/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1200	-
D6500/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1200

Closing Pressure \triangle Ps and linkage — D(U)6../S stainless steel disc series(on request)

		IP54 Actuator									IP67 Actuator						
Туре	NRVU [10Nm]	AI [151]	F Nm]	SRVU GRVU [20Nm]					SY1 SY2 [35Nm] [90Nm]		SY4 [400Nm]	SY6 [650Nm]	SY8 [1500Nm]	SY9 [2000Nm]			
	∆Ps kPa	∆Ps kPa	Linkage WD6	∆Ps kPa	∆Ps kPa	Linkage WD6	∆Ps kPa	Linkage WD6	∆Ps kPa	∆Ps kPa	∆Ps kPa	ΔPs kPa	∆Ps kPa	∆Ps kPa	∆Ps kPa		
DU650S	1200	1200	- AF	-	-	-	-	-	1200	-	-	-	-	-	-		
DU665S	1200	1200	- AF	-	-	-	-	-	1200	-	-	-	-	-	-		
DU680S	-	1200	- AF	1200	-	-	-	-	1200	-	-	-	-	-	-		
DU6100S	-	400	- AF	600	1200	- GR	-	-	1200	-	-	-	-	-	-		
DU6125S	-	-	-	-	600	- GR	1200	-2GR	-	1200	-	-	-	-	-		
DU6150S	-	-	-	-	-	-	1200	-2GR	-	1200	-	-	-	-	-		
DU6200S	-	-	-	-	-	-	400	-2GR	-	600	1200	-	-	-	-		
DU6250S	-	-	-	-	-	-	-	-	-	-	400	1200	-	-	-		
DU6300S	-	-	-	-	-	-	-	-	-	-	-	1200	-	-	-		
D6350S	-	_	-	-	-	-	-	-	-	-	-	-	1200	-	-		
D6400S	-	-	-	-	-	-	-	-	-	-	-	-	-	1200	-		
D6450S	-	-	-	-	-	-	-	-	-	-	-	-	-	1000	-		
D6500S	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1000		

D(U)6.. Butterfly valves, wafer or lug pattern







2-way Butterfly valves flanged

DN 50...500

For 2-point or modulating control of cold and hot water.


Applications

Typical applications include chiller isolation, cooling tower isolation, change - over systems, large air handling coil control, bypass and process control.

Technical data

Flow media	Chilled and hot water, sea water
Temperature of medium	-20°C+100°C
Rated pressure	1600 kPa (PN16)
Flow characteristic	Modified equal-percentage
Rangeability	10:1 (for 30° to 70° range)
Leakage rate	Bubble tight (to DIN 3230)
Pipe connections	Flange ISO 7005-2, PN6/10/16 for wafer and PN16 for lug
Closing pressure	See page 5
Mounting position	Vertical to horizontal
Maintenance	Maintenance-free
Angle of rotation	90° rotation
Materials	
Valve body	Cast iron GG25(DN50300) / Ductile iron GGG40 (DN350500)
Disc	Nylon coated ductile iron / Stainless steel 316 disc (on request)
Seat Shaft Bushing	EPDM boot seat 416 Stainless steel RPTFE

Ordering example



^{*} For linkage please refer to page 5.

Mode of operation

The Butterfly valve is operated by a rotary actuator. Both spring return or non-spring return actua tors are available. Select the actuator according to required close-off pressure and environmental condition of installation. The actuators are controlled by a standard Open/Close or modulating control system and move the disc of the valve to the position dictated by the control signal.


Product features


The large Kv values provide an economical control valve solution for larger flow applications.

Manual operation

Turn the valve by using a 20mm wrench with the manual button of NRVU..., SRVU.. or GRVU.. actuator pressed. The valve matched with SY actuator can be operated by turnning the wheel of SY2...9.. or via an 8mm wrench (SY1..).







Dimensions for PN16 lug pattern Butterfly valve

Туре	Size DN [mm]	Top flange Fxx	D1	D2	L1	L2	H1	H2	НЗ	G	ø1	n-M	Weight (Kg)
DU650L	50	F05	125	155	43	33	70	134	13	14	65	4-M16	3.2
DU665L	65	F05	145	175	46	48	76	147	13	14	65	4-M16	3.8
DU680L	80	F05	160	190	46	66	89	158	13	14	65	8-M16	5.0
DU6100L	100	F05	180	214	52	91	104	173	13	14	65	8-M16	9.0
DU6125L	125	F07	210	252	56	115	118	195	19	17	90	8-M16	11.3
DU6150L	150	F07	240	282	56	142	132	213	19	17	90	8-M20	15.0
DU6200L	200	F07	295	337	60	194	167	247	19	17	125	12-M20	20.0
DU6250L	250	F10	355	405	68	245	197	287	38	22	125	12-M24	30.0
DU6300L	300	F10	410	460	78	294	239	316	24	22	125	12-M24	46.0
D6350L	350	F10	470	524	79	328	265	345	24	22	125	16-M24	66.5
D6400L	400	F14	525	585	105	374	293	377	38	36	175	16-M27	96.0
D6450L	450	F14	585	645	112	425	327	412	38	36	175	20-M27	122.0
D6500L	500	F16	650	714	129	472	357	440	38	36	210	20-M30	202.0

Dimensions for PN6/10/16 wafer pattern Butterfly valve

Туре	Size		Da		1.0	1.11	110	1112	_	~1	Р	PN6 PN10 P		Р	N16	Weight	
тур	DN [mm]	flange Fxx	D2	L1	L2	H1	H2	H3	G	ø1	D1	n-ø	D1	n-ø	D1	n-ø	(Kg)
DU65	0 50	F05	93	43	33	70	134	13	14	65	110	4-14	125	4-19	125	4-19	2.3
DU66	5 65	F05	107	46	48	76	147	13	14	65	130	4-14	145	4-19	145	4-19	2.8
DU68	0 80	F05	123	46	66	89	158	13	14	65	150	4-19	160	8-19	160	8-19	3.5
DU61	00 100	F05	151	52	91	104	173	13	14	65	170	4-19	180	8-19	180	8-19	5.5
DU61	25 125	F07	177	56	115	118	195	19	17	90	200	8-19	210	8-19	210	8-19	7.4
DU61	50 150	F07	204	56	142	132	213	19	17	90	225	8-19	240	8-23	240	8-23	9.0
DU62	00 200	F07	260	60	194	167	247	19	17	125	280	8-19	295	8-23	295	12-23	15.0
DU62	50 250	F10	314	68	245	197	287	38	22	125	335	12-19	350	12-23	355	12-28	21.5
DU63	00 300	F10	370	78	294	239	316	24	22	125	395	12-23	400	12-23	410	12-28	32.3
D635	0 350	F10	422	79	328	265	345	24	22	125	445	12-23	460	16-23	470	16-28	43.5
D640	0 400	F14	473	105	374	297	377	38	36	175	495	16-23	515	16-28	525	16-31	64.0
D645	0 450	F14	526	112	425	331	412	38	36	175	550	16-23	565	20-28	585	20-31	83.25
D650	0 500	F16	577	129	472	361	440	38	36	210	600	20-23	620	20-28	650	20-34	165.1

NRVU.. Butterfly valve actuators

Technical data





- Non-spring return actuators, for operation of DN50...65 Butterfly valves
- Torque 10 Nm
- Open/Close or 3-point control: NRVU24(-S), NRVU230(-S)
- Modulating control: NRVU24-SR

NRVU24(-S)	Nominal voltage		AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage rar	nae	AC/DC 19.2 28.8 V
	Power consumption		2.0 W
	•	- holding	0.2 W
	For transformer/wir	e sizing	4 VA
	Connecting cable	- Motor	Cable 1 m, 3 x 0.75 mm ²
		 Auxiliary switch(-S) 	Cable 1 m, 3 x 0.75 mm ²
	Protection class		III (safety low voltage)
	Weight		NRVU24 approx 750g, NRVU24-S approx 850g
NRVU230(-S)	Nominal voltage		AC 100240 V 50/60 Hz
	Nominal voltage rar		AC 85265 V
	Power consumption	9	3.0 W
		- holding	0.6 W
	For wire sizing		7 VA
	Connecting cable	- Motor	Cable 1 m, 3 x 0.75 mm ²
		- Auxiliary switch(-S)	Cable 1 m, 3 x 0.75 mm ²
	Protection class		II (Totally insulated)
	Weight		NRVU230 approx 800g, NRVU230-S approx 850g
NRVU24-SR	Nominal voltage		AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage ran		AC/DC 19.2 28.8 V
	Power consumption	9	2.5 W 0.4 W
	For transformer/wir	- holding	5 VA
	Connecting cable	C SIZING	Cable 1 m, 4 x 0.75 mm ²
	Control signal Y		DC 010 V @ input resistance 100KΩ
	Operating range		DC 210V
	Measuring voltage	U	DC 210V@max. 1mA
	Synchronisation		±5%
	Protection class		III (safety low voltage)
	Weight		800 g
Common technical data	Torque		Min. 10 Nm @ nominal voltage
	Auxiliary switch (NF	RVUS)	1xSPDT 1 mA 3 (0.5) A, AC 250 V 0100% adjustable
	Angle of rotation		max. 90°
	Direction of rotation	1	Pre-setting to close(switch hidden under a label)
	Sound power level Position indicator		max. 45 dB(A) mechanical, remote visible
	Manual override		Gearing disengaged by pressing the pushbutton,
			manual operate while the button is held depressed
	Running time		90 s
	Mode of operation		EN 60730-1 Type 1
	Ambient temp.		-30°C+ 50℃
	Non-operation tem	0.	-40°C+ 80°C
	Humidity test		95% RH, non condensing (EN 60730-1)
	Degree of protectio	n	IP54 in any direction
	EMC		CE according to 89/336/EEC
	Low Voltage Directi	ve	CE according to 73/23/EEC
	Maintenance		maintenance free



Product features

Mode of operation

NRVU24-SR is controlled by means of a standard control signal DC 0...10V and travels to the position defined by this signal. The measuring voltage U allows the valve position (0...100%) to be electrically indicated and serves as a follow-up control signal for other actuators.

Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops.

High functional reliability

The actuator is overload-proof, requires no limit switches and automatically stops when the end

stop is reached.

Flexible signalization


Flexible signalization of the NRVU..-S with adjustable auxiliary switch (0...100%).


Simple mounting Includes WD6-NRSR linkage kit, see page 27.

Wiring diagrams

NRVU24(-S)

Open/Close control







Note

· Caution: Power supply voltage!

Please note the performance data

- Connection via safety isolating transformer.
- Other actuators can be connected in parallel. Please note the performance data.








L1



NRVU230-S


NRVU24




NRVU230(-S) Open/Close control N










AC 100...240 V



L1 AC 100...240 V

NRVU230

3-point control

N

Direction of rotation (factory setting,

Auxiliary switch(-S)

switch hidden)







0...100%

NRVU230

NRVU.. Butterfly valve actuators




NRVU24-SR

Modulating control

Notes

- Connection via safety isolating transformer.
- Other actuators can be connected in parallel.

 Please note the performance data.




Direction of rotation (factory setting, switch hidden)




Dimensions


Unit [mm]


NRVU24 NRVU230 NRVU24-SR





NRVU24-S NRVU230-S









- Non-spring return actuators, for operation of DN80...100 Butterfly valves
- Torque 20 Nm
- Open/Close or 3-point control: SRVU24(-S), SRVU230(-S)
- Modulating control: SRVU24-SR



3		
Technical data		
SRVU24(-S)	Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage range	AC/DC 19.2 28.8 V
	Power consumption - running	2.5 W
	- holding	0.2 W
	For transformer/wire sizing	5.5 VA
	Connecting cable - Motor	Cable 1 m, 3 x 0.75 mm ²
	- Auxiliary switch(-S)	Cable 1 m, 3 x 0.75 mm ²
	Protection class	III (safety low voltage)
<u></u>	Weight	SRVU24 approx 1000g, SRVU24-S approx 1050g
SRVU230(-S)	Nominal voltage	AC 100240 V 50/60 Hz
	Nominal voltage range	AC 85265 V
	Power consumption - running	3.0 W
	- holding	0.6 W
	For wire sizing	7 VA
	Connecting cable - Motor	Cable 1 m, 3 x 0.75 mm ²
	- Auxiliary switch(-S)	Cable 1 m, 3 x 0.75 mm ²
	Protection class	II (Totally insulated) □
	Weight	SRVU230 approx 1050g, SRVU230-S approx 1100g
SRVU24-SR	Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage range	AC/DC 19.2 28.8 V
	Power consumption - running	2.5 W
	- holding	0.4 W
	For transformer/wire sizing	5 VA
	Connecting cable	Cable 1 m, 4 x 0.75 mm ²
	Control signal Y	DC 010 V @ input resistance 100KΩ
	Operating range	DC 210V
	Measuring voltage U	DC 210V@max. 1mA
	Synchronisation	± 5%
	Protection class	III (safety low voltage)
	Weight	1050 g
Common technical data	Torque	Min. 20 Nm @ nominal voltage
	Auxiliary switch (SRVUS)	1xSPDT 1 mA 3 (0.5) A, AC 250 V
	Angle of rotation	max. 90°
	Direction of rotation Sound power level	Pre-setting to close(switch hidden under a label)
	Position indicator	max. 45 dB(A)
	Manual override	mechanical, remote visible Gearing disengaged by pressing the pushbutton,
	a.r.gar e rennae	manual operate while the button is held depressed
	Running time	90 s
	Mode of operation	EN 60730-1 Type 1
	Ambient temp.	-30°C+ 50°C
	Non-operation temp.	-40°C+ 80°C
	Humidity test	95% RH, non condensing (EN 60730-1)
	Degree of protection	IP54 in any direction
	EMC	CE according to 89/336/EEC
	Low Voltage Directive	CE according to 73/23/EEC
	Maintenance	maintenance free

SRVU.. Butterfly valve actuators



Product features

Mode of operation SRVU24-SR is controlled by means of a standard control signal DC 0...10V and travels to the position defined by this signal. The measuring voltage U allows the valve position (0...100%)

to be electrically indicated and serves as a follow-up control signal for other actuators.

Adjustable angle of rotation Adjustable angle of rotation with mechanical end stops.

The actuator is overload-proof, requires no limit switches and automatically stops when the end High functional reliability

stop is reached.

Flexible signalization Flexible signalization of the SRVU..-S with adjustable auxiliary switch (0...100%)

Simple mounting Includes WD6-NRSR linkage kit, see page 27.

Wiring diagrams

Notes


Open/Close control SRVU24(-S) 3-point control AC 24 V AC 24 V Ι Ι DC 24 V DC 24 V • Connection via safety isolating transformer. 2! • Other actuators can be connected in parallel. S1 S2 S3 S1 S2 S3 Please note the performance data. SRVU24-S SRVU24-S 0...100% 0...100% 0(Y1) Direction of rotation (factory setting, switch hidden) 1(Y2) SRVU24 SRVU24


SRVU230(-S)

Open/Close control

Note

- Caution: Power supply voltage !
- · Other actuators can be connected in parallel. Please note the performance data.






3-point control

Direction of rotation (factory setting, switch hidden)

Auxiliary switch(-S)











SRVU24-SR

Modulating control ⊥ ~ AC 24 V

+ DC 24 V

Notes


• Connection via safety isolating transformer. 🔼

Direction of rotation (factory setting,

switch hidden)

• Other actuators can be connected in parallel. Please note the performance data.






DC 0...10 V-


Dimensions


Unit [mm]





SRVU24-S SRVU230-S





GRVU.. Butterfly valve actuators

Technical data





 Non-spring return actuators, for operation of DN100...150 Butterfly valves, dual GRVU.. are for operation of DN125...200 Butterfly valves

• Torque 40 Nm

Open/Close control: GRVU24, GRVU230
 Modulating control: GRVU24-SR

GRVU24	Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage range	AC/DC 19.2 28.8 V
	Power consumption - running	4 W
	- holding	2 W
	For transformer/wire sizing	6 VA
	Connecting cable	Cable 1 m, 3 x 0.75 mm ²
	Protection class	III (safety low voltage)
	Weight	approx 1550 g
GRVU230	Nominal voltage	AC 100240 V 50/60 Hz
	Nominal voltage range	AC 85265 V
	Power consumption - running	4 W
	- holding	2 W
	For wire sizing	7 VA
	Connecting cable	Cable 1 m, 3 x 0.75 mm ²
	Protection class	II (Totally insulated) □
	Weight	approx 1550 g
GRVU24-SR	Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage range	AC/DC 19.2 28.8 V
	Power consumption - running	4.5 W
	- holding	2 W
	For transformer/wire sizing	6.5 VA
	Connecting cable	Cable 1 m, 4 x 0.75 mm ²
	Control signal Y	DC 010 V @ input resistance 100KΩ
	Operating range	DC 210V
	Measuring voltage U	DC 210V@max. 1mA
	Synchronisation	± 5%
	Protection class	III (safety low voltage)
	Weight	1550 g
Common technical data	Torque	Min. 40 Nm @ nominal voltage
	Angle of rotation	max. 95°
	Direction of rotation	Pre-setting to close (switch hidden under a label)
	Sound power level	max. 45 dB(A)
	Position indicator	mechanical, remote visible
	Manual override	Gearing disengaged by pressing the pushbutton, manual operate while the button is held depressed
	Running time	150 s
	Mode of operation	EN 60730-1 Type 1
	Ambient temp.	-30°C+ 50°C
	Non-operation temp.	-40°C+ 80°C
	Humidity test	95% RH, non condensing (EN 60730-1)
	Degree of protection	IP54 in any direction
	•	CE according to 89/336/EEC
	Low Voltage Directive	CE according to 73/23/EEC
	Maintenance	maintenance free



Product features

Mode of operation

GRVU24-SR is controlled by means of a standard control signal DC 0...10V and travels to the position defined by this signal. The measuring voltage U allows the valve position (0...100%) to be electrically indicated and serves as a follow-up control signal for other actuators.

Adjustable angle of rotation High functional reliability Adjustable angle of rotation with mechanical end stops.

The actuator is overload-proof, requires no limit switches and automatically stops when the end

stop is reached.

Accessories

Description

Electrical accessories (available on request)

Auxiliary switch S..A.. (WD6P needed)

Feedback potentiometer P..A.. (WD6P needed)

GRVU24

Positioner SG..24

Digital position indication ZAD24

Linkage kit

WD6-GR, for DN100...150 butterfly valve with single GRVU.. actuator, see page 28

WD6-2GR, for DN125...200 butterfly valve with dual GRVU.. actuators, see page 29

WD6P, for DU6... butterfly valve with Auxiliary Switch or potentiometer

Wiring diagrams


GRVU24


Open/Close control

AC 24 V DC 24 V



Notes • Connection via safety isolating transformer. 2!





Direction of rotation (factory setting, switch hidden)



Open/Close control GRVU230

Notes

- · Caution: Power supply voltage!
- Other actuators can be connected in parallel. Please note the performance data.

Direction of rotation (factory setting,

switch hidden)



0(Y1)

0(Y1)


L1 AC 100...240 V GRVU230


GRVU24-SR

Modulating control

Notes

- Connection via safety isolating transformer.
- Other actuators can be connected in parallel. Please note the performance data.






Measuring voltage U for position indicating or as master-slave control signal.



Dimensions Unit [mm]



AF.. Spring return actuators





• For operation of DN50...100 Butterfly valves

• Torque 15 Nm

• Open/Close control: AF24(-S), AF230 (-S)

• Modulating control: AF24-SR

Technical data		
AF24(-S)	Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage range	AC 19.2 28.8 V, DC 21.626.4 V
	Power consumption - running	5 W
	- holding	1.5 W
	For transformer/wire sizing	10 VA
	Connecting cable - Motor	Cable 1 m, 2 x 0.75 mm ²
	- Auxiliary switch(-S)	Cable 1 m, 6 x 0.75 mm ²
	Weight	3000 g
AF230(-S)	Nominal voltage	AC 230 V 50/60 Hz
	Nominal voltage range	AC 198264 V
	Power consumption - running	6.5 W
	- holding	2.5 W
	For wire sizing	11 VA
	Connecting cable - Motor	Cable 1 m, 2 x 0.75 mm ² Cable 1 m, 6 x 0.75 mm ²
	- Auxiliary switch(-S)	3300 g
	Weight	
AF24-SR	Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
	Nominal voltage range	AC 19.2 28.8 V, DC 21.628.8 V
	Power consumption - running	6 W 2.5 W
	- holding For transformer/wire sizing	10 VA
	Connecting cable	Cable 1 m, 5 x 0.75 mm ²
	Control signal Y	DC 010 V @ input resistance 100KΩ
	Operating range	DC 210V @ Input resistance 100K22
	Measuring voltage U	DC 210V@max. 0.5mA
	Synchronisation	± 5%
	Weight	2700 g
Common technical data	Torque - Motor	min.15 Nm
Common technical data	- Spring return	min.15 Nm
	Auxiliary switch(AFS)	2xSPDT 6 (3) A, AC250V 🗆
	realitary switch(tri. 6)	fixed 5% <1, adjustable 2894% <1
	Angle of rotation	max. 95°
	Direction of rotation - AF24(-S), AF230(-S)	selected by mounting side of L/R
	- AF24-SR	selected by mounting side of L/R or reversing switch
	Sound power level	-motor max. 45 dB(A), spring ≈ 62 dB(A)
	Position indicator	mechanical
	Manual override	hex crank
	Service life	≈60 000 operations
	Running time	motor ≈150s, spring return ≈ 16s
	Ambient temp.	-30°C+ 50°C
	Non-operation temp.	-40°C+ 80°C
	Humidity test	to EN 60335-1
	Degree of protection	IP54 CE according to 89/336/EEC, 92/31/EEC, etc
	EMC Low Voltage Directive	CE according to 89/336/EEC, 92/31/EEC, etc CE according to 73/23/EEC
	Maintenance	maintenance free
	Maintonuno	mamonunoo noo

Accessories

WD6-AF Linkage kit for DN50...100 butterfly valve with AF.. actuator, see page 26



Product features

Improved functional safety


The AF. actuator moves the valve to its normal working position while tensioning the return spring at the same time. If the power supply is interrupted, the energy stored in the spring moves the valve back to its safe position. The actuator is overload proof, needs no limit switches and halts automatically at the end stop.

Variable end switch

The AF24-S actuator has one fixed auxiliary switch and one adjustable auxiliary switch which allows angle of rotation of 5% and between 28...94% to be signalled.

Wiring diagrams






Notes

- Connection via safety isolating transformer. 2!
- Other actuators can be connected in parallel. Please note the performance data.









Note



Other actuators can be connected in parallel.
 Please note the performance data.








Notes

- Connection via safety isolating transformer.
- Other actuators can be connected in parallel. Please note the performance data.

Dimensions

Unit [mm]





 Non-spring return large torque actuators, for operation of DN50...500 Butterfly valves

Electric data

- Torque 35...2000 Nm
- Open/Close or 3-point control: SY..-24-3-T, SY..-230-3-T
- Modulating control: SY..-24P-T, SY..-230P-T



Technical data

Nominal voltage - SY24T - SY230T	AC 24 V 50/60 Hz AC 220 V 50/60 Hz
Power supply range - SY24T - SY230T	AC 21.6 26.4 V AC 198 253 V
Electrical connection Overload protection	½" cable connector, screw terminals Thermally protected 135°C cut-out
Motor protection	H class insulation (SY1), F class (SY29)
Gear train	High alloy steel gear sets
Operating range	SY3-T on/off, 3-point control
	SYP-T 2-10V DC, 4-20mA, 1-5V DC
	(selectable)
Sensitivity	0.2 mA / 100mV (for SY P-T only)
Feedback	4-20mA & 2-10VDC (for SY P-T only)
Angle of rotation range	Electrically limited to 90°, Max. 95° for manual operation
Position indication	Top mounted domed indication
Internal humidity control	Up to 95%, resistive heating element
Auxiliary switches	(2)SPDT, 3A 250VAC (SY1), 5A 250VAC (SY29)
Ambient temperature	-20°C 70°C
Housing type	IP67
Housing material	Die cast aluminium alloy
EMC	CE according to 89/336/EEC
Low voltage directive	CE according to 73/23/EEC, 93/68/EEC

Model	Torque	Motor	power	Running time Running c		g current	Manual	Weight	Mounting			
No.	(Nm)	24V AC	220V AC	24V AC	220 V 60Hz	V AC 50Hz	24V AC	220V AC	Override	(Kg)	flange (ISO 5211)	
SY1	35	10 W	10W	15s	12s	13s	0.6A	0.3A	by 8mm Wrench	2.0	F05	
SY2	90	70 W	40W	15s	15s	17s	3.0A	0.5A	Handwheel	11	F07	
SY3	150	70 W	40W	22s	22s	26s	3.0A	0.5A	Handwheel	11	F07	
SY4	400	180W	120W	16s	16s	18s	6.0A	0.6A	Handwheel	22	F10	
SY5	500	180W	120W	22s	22s	25s	6.5A	0.7A	Handwheel	22	F10	
SY6	650	/	120W	/	28s	31s	/	0.8A	Handwheel	22	F10	
SY7	1000	/	180W	/	46s	55s	/	1.6A	Handwheel	36	F14	
SY8	1500	/	220W	/	46s	55s	/	2.0A	Handwheel	36	F14	
SY9	2000	/	180W	/	58s	70s	/	1.6A	Handwheel	56	F16	

Product features

Electrical connections

All actuator control elements are wired to a terminal strip under the main cover. Remove the cover and insert the cables through the cable connector in order to reach the terminal strip. The connectors should be made according to the diagram. Before beginning this procedure, make sure that the power supply voltage is in accordance with the actuator's nameplate. After the terminal connections have been made, move the actuator manually to the half-open position and make a preliminary check of the wiring.

Manual operation


Turn the handwheel clockwise to close the actuator and anticlockwise to open. This provides a temporary manual operation. For a permanent manual operation, remove the power from the actuator. (Note: Need a 8mm wrench for SY1..)

Accurate positioning

The modulating actuator allows accurate positioning (< 2%). The sensitivity can be set to adjust the accuracy.



Designation



Accessories

Description

Electrical accessories

Feedback potentiometer SY-1000-FB (for SY..-3-T actuator)

Torque switch SY-26 (for SY2...SY6.. actuator)

Torque switch SY-712 (for SY7...SY9.. actuator)

Wiring diagrams

SY..-24-3-T

Open/Close or 3-point control ~ AC 24 V

Power supply Com/Neutral #3 Power supply Hot line for Open #4 Power supply Hot line for Close Connect to Com/Neutral for fully open indication

- Connect to Com/Neutral for fully close indication
- #7 Heater

Terminal

Auxiliary switch





Notes

- Connection via safety isolating transformer
- Relays are needed in parallel connection of several actuators
- "L1" cannot be connected to terminal #3 and #4 simultanenously.
- 30% duty cycle.

Open/Close or 3-point control

1 3 4 5 6 7

134567

Terminal

- #1 Power supply Com/Neutral
- Power supply Hot line for Open #3
- #4 Power supply Hot line for Close
- Connect to Com/Neutral for fully open indication
- Connect to Com/Neutral for fully close indication
- #7 Heater

Auxiliary switch





Notes

Notes

- · Caution: Power supply voltage!
- Relays are needed in parallel connection of several actuators
- "L1" cannot be connected to terminal #3 and #4 simultanenously.


• Connection via safety isolating transformer

• Power supply Com / Neutral and control signal "-" wiring to a common is prohibited.


• The control signal has to be separated from the others and shielded.

• 30% duty cycle.

SY .. - 24P-T




Modulating control



Terminal


#4	Power supply Com / Neutral
#5	Power supply Hot line
#6	Control signal -
#7	Control signal +
#8	For actuator internal use
#9	For actuator internal use
#10	For actuator internal use
#11	Feedback signal -
#12	Foodback signal +

Auxiliary switch




SY..-230P-T

SY..-230-3-T



Modulating control Terminal



Auxiliary switch






Notes

- · Caution: Power supply voltage!
- Power supply Com / Neutral and control signal "-" wiring to a common is prohibited.
- The control signal has to be separated from the others and shielded.
- 75% duty cycle.

• 75% duty cycle.





Dim. Model No.	А	В	С	D	Е	F	G	Н	I	J	K	М	N	S	Flange type
SY1	155 ¹⁾	114	8	19	15	-	14	50	6	45°	-	m6	2	1/2 PS	F05
SY2/3	289 2)	180	326	203	30	123	17/22	70	4	-	-	m8	2	1/2 PS	F07
SY46	317	217	394	290	40	194	22/35	102	4	-	-	m10	2	1/2 PS	F10
SY7/8	406	217	348	336	60	297	36	140	4	45°	180	m16	2	1/2 PS	F14
SY9	564	256	455	392	100	395	36	165	4	45°	221	m20	2	1/2 PS	F 16

Adjustments to SY.. large torque actuators



Circuit board set up (for modulating control actuator only)




Disconnect power supply before changing the following settings.
The words in bold are default settings.

Notes: VR1/VR2 are variable resistors for changing control signal to corresponding fully open/closed position.

Only authorized and trained persons are allowed to change the settings.





DIP switches setting

S1, S2 - fo signal	or Inp	ut	S3, S4, S5 - signal	for (Outpo	ut		S6 - Direction of travel in response to the control signal S7 & S8 - Actuator to the control signal					
Input signal	S1	S2	Output signal	S3	S4	S5	Symbol	S6	When signal fails	S7	S8		
2~10V	Off	On	2~10V	On	Off	On	90°	Off	Fully closed	Off	On		
4~20mA	On	Off	4~20mA	Off	On	Off	90° t		Fully open	On	Off		
1~5V	Off	Off					Y	On	Stop	On	On		


SW1~0: sensitivity switch

Position "0": Lowest sensitivity, $0\sim90^\circ$ divided into 17 steps. Position "1": Highest sensitivity, $0\sim90^\circ$ divided into 80 steps. The sensitivity decreases 7 times movement by sectors from SW1 to SW2, SW2 to SW3 and so on.



Position feedback

It is possible to add a potentiometer to provide feedback signal.



Potentiometer

For On/off actuator, the potentiometer SY-1000-FB is an option (on request), should be ordered together with the actuator.

When valve is closed: #8, #9 —-1K Ohm;

#9, #10—−0K Ohm

When valve is open: #8, #9 — OK Ohm;

#9, #10—-1K Ohm

For Modulating actuator, the potentiometer is a standard part and for actuator internal use only.




SY.. large torque actuator operation instructions

Travel cams TC..

Only authorized and trained persons are allowed to change the settings.


- TC1- for **open** position of limit switch (factory setting 90°).
- TC2 for closed position of limit switch (factory setting 0°).
- TC3 for open position of auxiliary switch (factory setting 87°).
- TC4 for closed position of auxiliary switch (factory setting 3°).



The cams for adjusting the limit and auxiliary switches are accessible if the cover is removed.


The LS2/LS1 limit switches interrupt the power supply to the motor and are controlled by means of the TC.. cams which rotate with the shaft. The LS4/LS3 auxiliary switches can optionally be connected for signalization purposes. The actuator closes the valve when the shaft turns clockwise (CW) and opens the valve when the shaft turns counterclockwise (CCW).

Adjusting the travel cam



- Loosen the travel cam to be adjusted with a 2.5 mm hexagonal key;
- 2. Turn the cam with the hexagonal key;
- 3. Adjust the cam as shown in the diagram and initial tighten the cam;
- Check the operation of the switch with power on;
- 5. Tighten the cams after successful adjustment.

Limiting of manual rotation angle



- 1. Stop screw for OPEN limiting
- 2. Stop screw for CLOSED limiting
- 3. Handwheel connection, for manual operation

Note: SY1 without the stop screws


The limiting of manual rotation angle is set at -2...92° in the factory.

The handwheel turns the planetary gear by means of a worm wheel. The gear is stopped mechanically by the two stop screws 1 and 2 (1 turn of the stop screw correspond to a 2° angle of rotation). When the motor stops at fully closed or open position, tighten the corresponding screw untill it touches the gearbox, turn the screw 1 cycle back and lock by an allen key and a wrench.

Note: The two limit switches LS2/LS1 are set at 0...90° angle. The LS2/LS1 switches must always switch off the motor **before** the effect of manual stop screws.

It is emphasized that the stop screws are only a safety feature to prevent overtravel when the actuator is being operated manually.

Relationship between the switches and travels



- 1. Auxiliary switches setting
- 2. Limit switches setting
- 3. Stop screws setting for manual operation

SY.. large torque actuator operation instructions



Open/Closed position setting

Closed position (0%) setting

- 1) For On/off actuator, wiring on terminal #1, #4; for modulating actuator, set Dip switch S7 "off", S8 "on", wiring on terminal #4, #5. (see Wiring diagram on page 20 and Circuit board set up on page 22)
- 2) Power on. The actuator will drive CW to fully closed position.
- Adjust travel cam TC2 in the closed position. (see page 23) For modulating actuator, firstly loose a fanshaped cam which connected with the potentiometer; retighten it after the successful setting of TC2.
- 4) Check whether LS2 switch trips prior to manual operation stop. (So when motor stops at fully closed position, it should be possible for further operating the handwheel CW 1/2...3/4 turn. Otherwise the stop screw for close need to be adjusted, see page 23)

Open position (100%) setting

- 1) For On/off actuator, wiring on terminal #1, #3; for modulating actuator, set Dip switch S7 "on", S8 "off", wiring on terminal #4, #5. (see Wiring diagram on page 20 and Circuit board set up on page 22)
- 2) Power on. The actuator will drive CCW to fully open position.
- Adjust travel cam TC1 in the open position. (see page 23) For modulating actuator, firstly loose a fanshaped cam which connected with the potentiometer; retighten it after the successful setting of TC1.
- 4) Check whether LS1 switch trips prior to manual operation stop. (So when motor stops at fully open position, it should be possible for further operating the handwheel CCW 1/2...3/4 turn. Otherwise the stop screw for open need to be adjusted, see page 23)

General

Cautions of installation

Make sure if the voltage is correct before wiring.

Re-place cover immediately after start-up and make sure that the seals are clean. Never fail to replace the protection cover. If water ever enter, dry thoroughly before re-placing cover. Don't reverse the motor head or install it upside down. Be sure to keep it away from gas, do not use in the explosive and chemical district. Power off before maintenance purpose. The On/Off frequency of the electric actuator is restricted according to the duty cycle, to avoid over heated.

Maintenance

All actuators are lubricated with anti-high temperature lubricant for long life and therefore require no special maintenance. The condition of the valve stem and its nut must be checked periodically to make sure they are clean and well lubricated. We recommend that a program of periodic maintenance should be drawn up for actuators that are operated infrequently.

Storage

The actuator includes elecetrical equipment as well as greese lubricated gear stages. Inspite of the weather proof enclosure, oxidation, jamming and other alterations are possible if actuator is not correctly stored. The actuators should be stored under a shelter in a clean, dry place, and protected from frequent changes in temperature. Avoid placing the actuators directly on the floor. The actuators are equipped with heat resistance, it is recommended that connect and give power supply to the actuator especially if the place of the storage is humid. Check that the temporary sealing plug of the cable entries are well in place. Make sure that the covers and boxes are well closed to ensure weather proof sealing.

Trouble shooting

Conditions	Possibilities	Solutions				
	Voltage abnormal	Check by multimeter.				
Motor overheat	High working frequency	Limit the working frequency.				
	Motor spindle is stuck or valve is too tight to move	Replace the stuck as semblies or the valve.				
	The gearbox stuck by stop screw	Check and correct travel cam for evidence of loosening; inspect the stop screw setting by operating the handwheel manually .				
	Power supply or voltage abnormal	Check the power supply voltage with the identification plate.				
No operation	Fuse blown	Check and replace the fuse as required.(except for HW-CB PCB)				
	Tripping of motor thermal protective device	Check if the motor is hot. The actuator will be available again after the motor is cooled down. Solve the motor overheat problem.				
Running motor stops	Power supply is short circuit	Check wiring.				
Running motor stops	Alienative object stuck in the pipe	Take off the valve for cleaning.				
Unable fully open/closed	The fixing screw for travel cam release	Re-adjust and tighten the travel cam.				
The actuator couldn't stop at the right position and hunting	The sensitivity setting is incorrect	Adjust the sensitivity switch SW1 to increase the number.				
Occasional fail in motor switched on or off	Power input of "on" and "off" simultaneously	Check if the external control switch is normal; relays are needed in parallel connection of several actuators.				



WARNING! Personal

injury or property

damage may result

where service con-

the valve ratings.

ditions could exceed

if the valve is installed

D(U)6.. valve installation and maintenance instructions

installation and maintenance instructions

Pre-installation procedure

- Be certain the adjoining pipeline is free from any foreign material such as rust and pipe scale or welding slag that could damage the seat and disc sealing surfaces.
- Any actuator should be mounted on the valve prior to installation to facilitate proper alignment of the disc in the valve seat.
- 3) Check the valve identification tag for materials, and operating pressure to ensure they are correct for the application.
- 4) Check the flange bolts or studs for proper size, threading and length.

Valve installation procedure

Position the connecting pipe flanges in the line to insure proper alignment prior to valve installation. Spread the pipe flanges apart enough to allow the valve body to be located between the flanges without actually contacting the flange surfaces (See Figure 1). Exercise particular care in handling the valve so as to prevent possible damage to the disc or seat faces.

- 1) For both wafer and lug valves: a. Place the valve between the flanges. b. Install all bolts between the valve and the mating flanges. Hand tighten bolts as necessary.
- 2) Before completing the tightening of any bolts, the valve should be centered between the flanges and then carefully opened and closed to insure free, unobstructed disc movement (see Fig.2).
- 3) Tighten the flange bolts evenly to assure uniform compression.
- 4) If an actuator is to be used, electricity should be connected to the unit as specified by the actuator manufacturer.
- 5) Cycle the valve to the fully open position, then back to the fully closed position, check the actuator travel stop settings for proper disc alignment. The valve should be operated to assure that no binding is taking place.
- 6) The valve is now ready for operation.

Safety precautions

Before removing the valve from the line or loosening any bolts, it is important to verify the following conditions:


- 1) Be sure the line is depressurized and drained.
- Be sure of the pipeline media. Proper care should be taken for protection against toxic and/or flammable fluids.
- 3) Exercise caution if removing the actuator from the valve when the pipeline is under pressure. The valve disc may move suddenly due to the pressure.
- 4) Always be sure that the disc is in the close position before removing the valve.

General maintenance

The following periodic preventative maintenance practices are recommended for all butterfly valves:


- 1) Operate the valve from full open to full closed to assure operability.
- Check flange bolting for evidence of loosening and correct.
- Inspect the valve and surrounding area for previous or existing leakage at flange faces or shaft connections.
- Check piping and/or wiring to actuators and related equipment for looseness and correct as needed.

Figure 1 Initial installation of valve



Incorrect


Disc opened beyond valve body face. Pipe flanges not spread sufficiently.



Correct

Disc positioned in the almost closed position. Pipe flanges spread allow sufficient room for valve.


Figure 2 Centering and flanging of valve



Incorrect

Disc in closed position. Gaskets installed between valve and mating flanges


Remember : Install the valve with the disc in the "ALMOST CLOSED" position. Do not use any flange gasket.



Correct


No flange gaskets used. Disc in the "almost closed" position.

Figure 3 Final valve alignment and tightening of flange bolts



Incorrect

Pipe flanges mis-aligned. Uneven torque applied to bolting.





Correct


Piping aligned. Thread engagement even on both sides of valve.


WD6-AF linkage kits installation instructions








































WD6-GR linkage kit installation instructions



















































SY.. actuator installation instructions










2









Innovation, Quality and Consultancy: A partnership for motorizing HVAC actuators



Belimo regional head offices

- EU BELIMO Automation AG Brunnenbachstrasse 1 8340 Hinwil, Switzerland Tel. + 41 43 843 61 11 Fax: + 41 43 843 62 68 E-Mail: info@belimo.ch
- AP BELIMO Actuators Ltd. Shanghai Office
 4th Floor, Ximmao Building
 99 Tianzhou Road Caohejing Hi-Tech Park
 Shanghai 200233, P. R. China
 Tel. + 86 21 5445 0601
 Fax: + 86 21 5445 0602
 E-mail: info.asiapacific@belimo.ch
- US BELIMO Aircontrols (USA), Inc. 43 Old Ridgebury Road Danbury, CT 06813-2928, USA Tel. + 800 543-903 / 203 791-9915 Fax: + 800 228-8283 / 203 791-9919

